Code (VM, VS, VP,VPD)	Description
1200	1 Gang Blank Plate
1201	2 Gang Blank Plate

Vimark

Vimark Series – Blank Plates

Features

- **Vimark Pro/Square (VP/VS)**: High grade urea front plate with antimicrobial properties

Safety Instructions - If in doubt, contact a qualified electrician

1. These instructions should be read carefully and retained after installation for future reference and maintenance.
2. This product should be installed in accordance with current edition of IET wiring regulations, BS 7671 and local building regulations.
3. Always switch off the mains electrical supply at the consumer unit before commencing installation.
4. **Vimark Pro/Square/ Décor (VP/VS/VPD):** Use appropriate size metal, dry lining or pattress mounting boxes
5. Metal mounting boxes must be earthed and plastic grommets must be used to protect cable insulation.
6. When preparing cables, strip insulation to correct length to allow the conductors to reach the terminals of your connectors of choice (screwed connector blocks or screwless connectors.)
7. Earth conductors must be sleeved with green/yellow insulation sleeving.
8. **When choosing a connector for making safe electrical connections behind a blank plate, ensure it is of a suitable voltage and current rating for the application.** If in doubt, contact a qualified electrician.

Environmental Instructions

This product may contain substances that can be hazardous to the environment if not disposed of properly. Waste electrical and electronic equipment (WEEE) should never be disposed of with general household waste but must be separated for its correct treatment and recovery. Where possible recycle your packaging.

Installation Instructions

Wiring colours

As of April 2004, twin and earth cable core colours for all new fixed wiring installation in the UK have been updated. Refer to table below for twin and earth wiring colours identification.

	Wiring colours	
	Pre April 2004	**Post April 2004**
Live	Red	Brown
Neutral	Black	Blue
Earth	Yellow/Green	Yellow/Green

SUGGESTED METHOD OF INSTALLATION

Read instructions and check you have all the tools and accessories to complete the installation safely and in compliance with current electrical regulations

1. Ensure the electrical supply is switched off.
2. **Vimark Pro/Square/Décor (VP/VS/VPD):** Install a metal/pattress box on a wall and route the cabling through a knockout on the box. **Vimark Metalclad (VM):** Install the 'Metalclad' backbox on the wall and route the cabling through a knockout on the box.
3. Prepare the cables by stripping the Live, Neutral and Earth wires to required length.
4. Insert the Live, Neutral and Earth wires into the connector of choice, connecting the Lives together, the Neutrals together and the Earths together. Tighten the screws of each terminal if using a screw connector, snap shut the levers if using a screwless lever connector, or push the conductors into place if using a push fit connector. Ensure no conductor material is showing outside of the connector and that all connections are tight and secure.
5. If a metal mounting box is installed, it must be earthed; and bare earth conductors must be sleeved with green/yellow insulation sleeving.
6. **Vimark Pro/Square/Décor (VP/VS/ VPD):** Screw the blank plate onto the metal/pattress box on the wall using the screws provided. **Vimark Metalclad (VM):** Screw the blank plate onto the mounted backbox with the screws provided.
7. Switch on the power supply.

Specification

Input Voltage	n/a	Mounting Box Recommended Depth	VP/VS/VPD	25mm
			VM	38mm
Current Rating	n/a	Compliance		BS 5733

INS0877 V1.0 11/24 NPD 0738/0774/0777/0841

Deta Electrical Company Limited
UK: Panattoni Park Luton Road Chalton Bedfordshire LU4 9TT
EU: Unit 16 Ashbourne Ind. Est. Ashbourne Co. Meath A84 W972
deta.co.uk | Technical Helpline: +44(0)1582 544 548