ISO 9001 CERTIFIED


HEAD OFFICE, NORWAY
DNH AS
Phone..... + 47 35 98 56 00
E-mail.....dnh@dnh.no
Web-Site..... www.dnh.no


ENGLAND
DNH WW Ltd
Phone.....+ 44 1908 275 000
Fax.....+ 44 1908 275 100
E-mail.....dnh@dnh.co.uk


GERMANY
DNH GmbH
Phone... + 49 040 6569 30-0
Fax..... + 49 040 6569 30-30
E-mail..... dnh@dnh.de

USA
DNH Speakers Inc
Phone..... + 1 484 494 5790
Fax.....+ 1 484 494 5793
E-mail..dnh@dnhspeakers.com

BKF-560(T)








70/100 Volt combined transformer Primary connections	
White : Green	70 V
White : Red	100 V

Secondary nominal tappings	
C : 6W	6,0 W
C : 3W	3,0 W
C : 1,5W	1,5 W
C : 0,5W	0,5 W

Sound pressure levels at 1W/1m w/P-5/15T



Specifications	
Material / Color	Aluminum / RAL9010
Plastic dust box	UL94-V0
Mounting	Springs
Termination	Spring clamps
Weight	0,74 kg
Max. / min. amb. temp	90°C / -20°C
Rated power	6W
IP	32
SPL 1W/1m	90 dB
SPL rated power	97 dB
Effective freq. range	140 – 20000 Hz
Dispersion (-6dB) 1kHz / 4kHz	160° / 55° (baffle)
Options	Impedances, colors, labels

Installation, Operation and Maintenance Procedures

- Remove box by one screw, lead cable trough the cable gland, connect to terminal (70V or 100V) and select required tapping into the transformer.
- Install box by one screw to loudspeaker and mount the complete loudspeaker by bending back two spring clamps and inserting into the ceiling hole.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- Do not open loudspeaker when energized.
- This loudspeaker is supplied with two years warranty against defective workmanship.

CE

DNH reserves the right to alter specifications without notice